



## NATERIALS

You will need • Disposable gloves
• Thick foam sponge • Fast-setting
mortar (I used Cemix Quick Patch,
which is enough to make about five
pots) • Old bucket or container
• Water • Round balloons (make
sure the packet specifies that
they're round, not oval) • Cotton
buds • Paintbrush • Painter's
masking tape • Resene Quick Dry
Primer • Resene test pots (I used
Resene Metallics Magma)
Cost: \$45 excluding paint.

Create a concave hollow in the sponge large enough to cradle the balloon as you apply the mortar. Blow the balloon up to your desired size and place it, tied end down, into the concave hole. Or make a small hole that goes through the sponge and pull tied end of the balloon through.

**2** Mix up mortar and water until you have a thick icing-like consistency. Wearing gloves, apply mortar to the top half of the balloon (which will eventually end up as the bottom of your pot). Feather out the edges onto the exposed half of the balloon.

Wet your gloved hands and smooth out the mortar. Without popping the balloon, gently create two or three drainage holes in the top of the mortar shape with a cotton bud. Leave to set.

Once set, remove the balloon from the sponge, turn it over and apply more mortar mix to the top end of the balloon. Create an interesting opening, then feather the wet mortar over the dry feathered mortar to maintain a consistent thickness.

Smooth out the wet mortar with wet gloved hands. Leave to dry.

Pop the balloon, then add a layer of mortar to the inside of the pot to strengthen it.

Make sure the drainage holes are clear of mortar before it sets.

6 Prime and paint your pot. Remember to use painter's masking tape if you want to paint sections of the pot.

Watch our video on how to make this at: play.stuff.co.nz/details/\_6214983034001