Resene

Bentwood chair



Difficulty level ★easy ★★moderate ★★★challenging

Fun with furniture with Mark Rayner - 28

You will need:

- Clean cloth
- Old bentwood chair
- Paintbrush
- Resene Lustacryl tinted to Resene All Black and Resene Pohutukawa
- Resene Quick Dry
- Resene testpots of Resene Bullion and Resene Porsche
- Sandpaper
- Wood filler and knife for filling



Step one

Fill any imperfections in the chair with wood filler. Allow to dry and lightly sand the whole chair with sandpaper.



Step two

Wipe off any sanding residue with a clean cloth and allow to dry.



Step three

Apply one coat of Resene Quick Dry to the chair and allow two hours to dry.



Step four

Apply one coat of Resene Porsche to the outer rim of the seat and allow two hours to dry.



Step five

Apply two coats of Resene Bullion to the outer rim of the seat, allowing two hours for each coat to dry.



Step six

Apply one coat of Resene All Black to the underside, legs and back of the chair, allowing two hours to dry.



Step seven

Apply a second coat of Resene All Black to the underside, legs and back of the chair. Again, allow two hours to dry.



Step eight

Apply two coats of Resene Pohutukawa to the seat, allowing two hours to dry. Make a real statement with this theatrical twist on a traditional bentwood chair.



To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Corn Field.



Other ideas:

Create a clean contemporary look with a combination of Resene Double Alabaster, Resene Silver Chalice and Resene Silver Aluminium.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/ artists_canvas.htm

www.resene.com.au/ artists/artists_canvas.htm.



